

THOMSON

With the TV in standby:

Press and hold the {VOL -} & {PRG -} buttons on the TV.

Keep both buttons pressed until the TV turns On with the Service Menu displayed.

To exit, turn the TV Off.

While the TV is On, press the {POWER} button on the remote control to put TV in standby.

Turn the TV Off using the {POWER} button on the TV.

Using the buttons on the TV:

Turn the TV On while pressing the {PRG -} & {VOL -} buttons

The Service Menu will be displayed.

To exit, turn the TV Off.